


Prosport Inc. Premium Clock Gauge

Amber/White Display

1. Wiring Back of Gauge



2. Time set mode:

Press and hold button for 5 sec. You will now enter time set mode. Once the needles begin to flash, Press and hold or toggle button. Needles will begin to spin to desired Time. Release or stop toggle once desired time is reached. Let gauge sit for 5 seconds, it will now be in active mode.

FAQ: My clock does not retain Memory, What do i do??

Answer: The red wire needs to be on a constant 12v.

Will the gauge kill my battery if its on a constant 12v???

Answer: No, the gauge draws under 3ma.

Lighting Diagram

Day Time	Night Time	Installation
White	White	White — Connect to acc. Power Amber — Do not connect
Amber	Amber	White — Do not connect Amber — Connect to acc. Power
White	Amber	White — Connect to acc. Power Amber — Connect to parking lamp
Amber	White	Amber — Connect to acc. Power White — Connect to parking lamp

